

AA Tuning Supercharger Maintenance Items

OIL SERVICE	Replace engine oil & filter at least every 3,000 miles with good quality synthetic oil	Mobil 5w30, 10w30 Castrol 5w30, 10w30 BMW Synthetic 5w30 Motul 5w40
OIL FILTER		11-42-1-730-389 Oil Filter 1993 BMW 325i 1995 BMW M3 1996-1999 BMW M3 11-42-1-427-908 Oil Filter 1996-1998 BMW 328i
DIFFERENTIAL	Replace oil with Redline 85W140 GL5 gear lube every 7500-10,000 miles	Redline 85w140 GL5
SPARK PLUG	Replace with factory spark plugs every 10,000 - 15,000 miles	12-12-9-063-428 F7LDCR 1993-1995 BMW 325i 12-12-9-069-877 FGR8KQC 1996-1998 BMW 328i, M3
AIR FILTER	AA SC USES K&N air filters	RU3190 1993-1995 BMW 325i 1996-1998 BMW 328i 1995-1999 BMW M3 RU3130 2001 BMW 330i
SC BELT	Check every 5,000 miles	5060880 6PKx2236 with 85mm Pulley 1993-1995 BMW 325i 1996-1998 BMW 328i 1995 BMW M3 1996-1999 BMW M3 679-2240 6PKx2240 with 90mm Pulley 1993-1995 BMW 325i 1996-1998 BMW 328i 1995 BMW M3 1996-1999 BMW M3
SC OIL	Check oil level every 5,000 miles. Replace with Rotrex friction oil every 40,000 to 50,000 miles or	6539002 SC traction oil SX100

	every 2 years if driven less than 5,000 miles per year	
BRAKE FLUID		BMW Specified 2 Year Interval
COOLANT		BMW Specified 2 Year Interval